





# Pour démarrer



1	An illustration of a hand tapping a Sphero robot. Two red arrows point downwards from the hand, indicating the direction of the taps.	Taper 2 fois sur Sphero.
2	An illustration of a hand tapping a blue app icon on a screen. The icon features a white Sphero robot face.	Ouvrir l'application.
3	A screenshot of the Sphero app interface. It shows various settings and options, including a section for 'Mise à jour firmware' and 'Mise à jour de l'OS'. A red arrow points to the 'Mise à jour de l'OS' option.	Ouvrir « Réglages - Bluetooth » pour appairer Sphero.
4	A blue button with a white icon of a hand holding a Sphero robot. The icon has two curved arrows pointing outwards, indicating a 'press and hold' action.	Appuyer et maintenir le pictogramme « AIM » afin de régler l'objectif.
5	A diagram showing a circle with a blue dot at the bottom. The circle is divided into four quadrants by a vertical line and a horizontal line. The angles are labeled: 90° at the top, 180° at the bottom, 270° on the left, and 0° at the top. Below the circle is a small illustration of the Sphero robot with a blue light on its top.	Pour déterminer l'avant de l'arrière, faire tourner la petite lumière bleue jusqu'à ce qu'elle soit devant vous.

# Pour fermer



1		Revenir à l'écran d'accueil.
2		Cliquer 2 fois sur le bouton central.
3		Faire glisser l'application vers le haut.
4		Replacer Sphero sur sa base et recharger.

Images : [sphero.com](http://sphero.com)